

HP Insight Control Environment RDP Upgrade



These activation instructions can also be found at <http://www.hp.com/go/ice-license>.

HP Insight Control Environment RDP Upgrade includes two separate license keys. For successful operation both licenses must be applied to each managed target system. These licenses are for environments where HP Insight Rapid Deployment software is already installed and licensed. Starting with version 2.30, Insight Control Environment can be used for ProLiant c-Class blades as well as ProLiant ML and ProLiant DL 300/500/700 series servers.

License Key 1: The Insight Control Environment key contains hidden subkeys for HP Insight Power Manager software, HP Virtual Machine Management Pack, HP Performance Management Pack, and HP Vulnerability and Patch Management Pack.

If you are using Insight Control Environment 3.00, you must use the HP Insight Software 3.00 integrated installer to enable the suite licensing. Starting with version 3.00, the Insight Control Environment licensing is now done from the Deploy -> License Manager menu.

Note: The product will not be listed until you add the first key.

To add a key from HP Systems Insight Manager:

1. Go to **Deploy -> License Manager**
2. Select **Add Licenses**.
3. Enter the key in the **Specify Key String** field. Click **Process**.
4. When key details appear, click **Add Licenses Now**.

To apply a license to a system from Deploy -> License Manager:

1. Go to **Deploy -> License Manager**
2. Select **Insight Control Environment** in the Product License Information list, and then click **Manage Licenses**.
3. A list of license keys appears. Click **Apply Licenses**.
4. Select the systems to license, then click **Apply** and **Next**.
5. Select the unlicensed systems and then click **Select License**.
6. Select the license key to use, and then click **Apply License**.

If you are using Insight Control Environment 1.xx or 2.xx, you must use the HP Insight Control Management integrated installer to enable the suite licensing. The menus will not appear until at least one HP ProLiant BladeSystem or ML/DL server has been correctly discovered.

To add a key in HP Systems Insight Manager:

1. Go to the Deploy -> License Manager menu
2. Click **Add Licenses**.
3. Enter the key in the **Specify Key String** field. Click **Process**.
4. When key details appear, click **Add Licenses Now**.

To apply a license to a system:

1. Go to **Deploy -> Insight Control Licenses -> Insight Control Environment Keys (ML/DL)**
2. Select the systems to license, then click **Apply** and **Next**.
3. Select the unlicensed systems and then click **Select License**.
4. Select the license key to use and then click **Apply License**.

License Key 2: Your iLO Advanced license key activates iLO Advanced features. These instructions assume the network client has a network connection to the iLO or iLO 2 management processor.

To install the iLO Advanced license and enable iLO Advanced functionality using a supported web browser:

1. Log in to iLO or iLO 2 with a user ID that has the Configure iLO Settings privilege.
2. Click the **Administration** tab, then click **Licensing**.
3. Enter the 5 x 5-character license key in the space provided.
4. Click **Install**. The End User License Agreement (EULA) confirmation displays. The EULA details are available with the license kit.
5. Click **OK** to accept the terms of the EULA enclosed with this product. The licensed features are now enabled.

Note: If you purchased HP Insight Control Environment for BladeSystem RDP Upgrade, license key 2 contains iLO Advanced for BladeSystem instead of iLO Advanced. Follow the License Key 2 instructions listed above using the iLO Advanced for BladeSystem license key.

The following resources are available on the web at www.hp.com/go/ice:

- Access to software downloads
- Installation and usage guides
- Support and services information

You can order the HP Insight Software media kit for your product directly from HP or your preferred reseller. HP recommends that you download and install the latest product software from the URL listed above.

Support and Software Updates

One year of 24x7 Software Technical Support and Software Updates is included with this software. For more information about this service, see www.hp.com/services/insight. After HP processes your support registration, you will receive a Service Agreement Identifier (SAID). To receive the software updates that you are entitled to, you must use your SAID and access the Software Update Manager (SUM) at the HP IT Resource Center (ITRC) home page: www.itrc.hp.com.

Count on HP for Software Support Solutions

The following support upgrade options are available:

- Three years of 24x7 Software Technical Support and Software Updates
- Four years of 24x7 Software Technical Support and Software Updates
- Five years of 24x7 Software Technical Support and Software Updates

To upgrade your support, or for technical issues using Insight Control products purchased through HP, contact an HP support center:

http://welcome.hp.com/country/us/en/wwcontact_us.html

Software is subject to the terms and conditions described in the End User License Agreement (EULA). During installation, be sure to read the EULA carefully before proceeding.

HP Insight Control Environment RDP Upgrade



これらのアクティベーション手順は、HPのWebサイト<http://www.hp.com/jp/ice-license>にも記載されています。

HP Insight Control Environment RDP Upgradeには、2つの独立したライセンス キーが含まれています。各管理対象システムが正常に動作するために、両方のライセンスを適用する必要があります。これらのライセンスは、HP Insight Rapid Deploymentソフトウェアがすでにインストールおよびライセンス適用された環境を対象にしています。バージョン2.30以降のInsight Control Environmentは、ProLiant c-Class ブレード、ProLiant MLおよびProLiant DL 300/500/700シリーズのサーバで使用できます。

ライセンス キー1：Insight Control Environmentキーには、HP Insight Power Managerソフトウェア、HP Virtual Machine Management Pack、HP Performance Management Pack、およびHP Vulnerability and Patch Management Pack用の隠しサブキーが含まれています。

Insight Control Environment 3.00を使用する場合は、HP Insight Software 3.00統合インストーラを使用してスイートのライセンスを有効にする必要があります。Insight Control Environmentのバージョン3.00以降では、[展開]から[ライセンス マネージャ]メニューにアクセスしてライセンスを適用します。

注：最初のキーを追加しないと、製品はリストに表示されません。

HP Systems Insight Managerからキーを追加するには、以下の手順に従ってください。

1. [展開]、[ライセンス マネージャ]の順に移動します。
2. [ライセンスの追加]を選択します。
3. [キー スtringの指定]フィールドにキーを入力します。[処理]をクリックします。
4. キーの詳細が表示されたら、[今すぐライセンスを追加]をクリックします。

[展開]、[ライセンス マネージャ]の順に選択してシステムにライセンスを適用するには、以下の手順に従ってください。

1. [展開]、[ライセンス マネージャ]の順に移動します。
2. [製品ライセンス情報]リストで[Insight Control Environment]を選択し、[ライセンスの管理]をクリックします。
3. ライセンス キーのリストが表示されます。[ライセンスの適用]をクリックします。
4. ライセンスを適用するシステムを選択して、[適用]、[次へ]の順にクリックします。
5. ライセンスが適用されていないシステムを選択して、[ライセンスの選択]をクリックします。
6. 使用するライセンス キーを選択して、[ライセンスの適用]をクリックします。

Insight Control Environment 1.xxまたは2.xxを使用する場合は、HP Insight Control Management統合インストーラを使用してこのスイートのライセンスを有効にする必要があります。1台以上のHP ProLiant BladeSystemまたはML/DLサーバが正常に検出されるまでは、メニューは表示されません。

HP Systems Insight Managerでキーを追加するには、以下の手順に従ってください。

1. [展開]、[ライセンス マネージャ]メニューの順に移動します。
2. [ライセンスの追加]をクリックします。
3. [キー スtringの指定]フィールドにキーを入力します。[開く]をクリックします。
4. キーの詳細が表示されたら、[今すぐライセンスを追加]をクリックします。

システムにライセンスを適用するには、以下の手順に従ってください。

1. [展開]、[Insight Controlライセンス]、[Insight Control Environment キー (ML/DL)]の順に移動します。
2. ライセンスを適用するシステムを選択して、[適用]、[次へ]の順にクリックします。
3. ライセンスが適用されていないシステムを選択して、[ライセンスの選択]をクリックします。
4. 使用するライセンス キーを選択して、[ライセンスの適用]をクリックします。

ライセンス キー2：iLO Advancedのライセンス キーを使用して、iLO Advancedの機能を有効にできます。これらの手順は、ネットワーククライアントがiLOまたはiLO 2管理プロセッサにネットワーク接続できることを前提としています。

サポートされているWebブラウザを使用して、iLO Advancedのライセンスをインストールし、iLO Advancedの機能を有効にするには、以下の手順に従ってください。

1. iLOの設定権限を持っているユーザIDを使用して、iLOまたはiLO 2にログインします。
2. [管理]タブ、[ライセンシング]の順にクリックします。
3. 5×5文字のライセンス キーを、スペースに入力します。
4. [インストール]をクリックします。エンド ユーザ使用許諾契約書 (EULA) の確認画面が表示されます。EULAの内容の詳細は、ライセンス キットから入手できます。
5. この製品に付属のEULAの内容に同意する場合は、[OK]をクリックします。これで、ライセンスを適用された機能が有効になります。

注：HP Insight Control Environment for BladeSystem RDP Upgradeを購入した場合、ライセンス キー2にはiLO AdvancedではなくiLO Advanced for BladeSystemが含まれます。上記のライセンス キー2の手順では、iLO Advanced for BladeSystemのライセンス キーを使用してください。

HPのWebサイト<http://www.hp.com/jp/insightcontrol>から以下のリソースを使用できます。

- ソフトウェアのダウンロード
- インストールおよび使用方法のガイド
- サポートおよびサービス情報

ご使用の製品のHP Insight Softwareメディア キットは、HPに直接、またはご希望の販売店に注文できます。上記のURLから最新のソフトウェア製品をダウンロードおよびインストールすることをおすすめします。

サポートおよびソフトウェア アップデート

このソフトウェアには、1年間、24時間年中無休のソフトウェア テクニカル サポートおよびソフトウェア アップデートが含まれています。代理店経由でお買い上げいただいたお客様は、製品に同梱の『保守情報登録シート』での登録手続きをお願い致します。（ただし、HPの営業担当から直接お買い上げいただいた場合は、シートでの登録手続きは不要となります。）このサービスについて詳しくは、保守登録処理完了後に送付されるサービス仕様を参照してください。HPによるお客様のサポート登録処理が完了すると、SAID (Service Agreement Identifier) が送付されます。利用可能なソフトウェア アップデートを受け取るには、HP ITリソース センタ (IT Resource Center) のホームページ <http://www.itrc.hp.com> から、SAIDを使用してソフトウェア アップデート マネージャ (SUM) にアクセスする必要があります。

信頼性の高いHPのソフトウェア サポート ソリューション

以下のサポート アップグレード オプションがあります。

- 3年間、24時間年中無休のソフトウェア テクニカル サポートおよびソフトウェア アップデート
- 4年間、24時間年中無休のソフトウェア テクニカル サポートおよびソフトウェア アップデート
- 5年間、24時間年中無休のソフトウェア テクニカル サポートおよびソフトウェア アップデート

サポートのアップグレード、またHPから購入したInsight Control製品の使用に関する技術的な問題については、HPのWebサイト http://welcome.hp.com/country/jp/ja/contact_us.html から、HPのサポートセンタにお問い合わせください。

ソフトウェアは、エンド ユーザ使用許諾契約書 (EULA) の規定に基づき使用されるものとします。インストール時には、必ずEULAをよくお読みいただいてから作業してください。